

# Installation Guide

KDE88-8B  
KDE8-8D  
KDE8-4B4D



## Instructions

### Dome Camera Installation:

1. Unscrew the top portion of the base from the bottom portion.
2. Mount camera base to wall or ceiling.
3. Connect the BNC Connection attached to the camera to your cable.
4. Connect the Power Connection attached to the camera to your cable.
5. Attach top portion of base with Dome cover to the bottom portion (mounted) of the base.

### Bullet Camera Installation:

1. Mount bracket to wall where camera will be placed.
2. Mount camera to bracket.
3. Connect the BNC Connection attached to the camera to your cable.
4. Connect the Power Connection attached to the camera to your cable.

### DVR Installation:

1. Plug all 4 camera cables into the back of the DVR.
2. Connect to monitor (not included).
3. Plug in (power on) DVR.

## Warranty Information

Opticom Technologies provides a one (1) year parts and labor warranty on this camera. This product is warranted to be free from defects in workmanship and material under normal use. Normal operation includes use of the camera as part of a closed circuit television system or other reasonable application to which the camera may be suited.

This warranty specifically excludes damage caused by misuse, abuse, alterations, water damage, external shorting, applying incorrect voltage, reversing polarity, static electrical damage, or failure to properly mount the camera.

### Product Returns

In order to expedite goods returned to Opticom for warranty, replacement, or non-warranty repair, please call 888-410-2447 to obtain an RMA number.

